


Canonet
G-III 17



E




- | | |
|-----------------------------------|-----------------------------|
| ① Focusing Lever | ⑨ Flash Socket Safety Cover |
| ② Selftimer Lever | ⑩ Film Rewind Crank |
| ③ Shutter Speed Ring | ⑪ Film Plane Indicator |
| ④ AUTOMATIC/MANUAL Aperture Ring | ⑫ Accessory Shoe |
| ⑤ ASA Film Speed Indicator Window | ⑬ Frame Counter |
| ⑥ Automatic EE Mark | ⑭ Shutter Button |
| ⑦ Focusing Ring | ⑮ Cable Release Socket |
| ⑧ Viewfinder Window | ⑯ Film Advance Lever |



- ①⑦ Blue Lamp
- ①⑧ Battery Check Button
- ①⑨ Viewfinder Eyepiece
- ②⑩ Film Transport Indicator
- ②⑪ Film Indicator
- ②② Mercury Battery Compartment
- ②③ Tripod Socket
- ②④ Film Rewind Button

- ②⑤ Bulb Exposure Setting Lever
- ②⑥ Film Speed Setting Lever
- ②⑦ Simple Exposure Symbols


Mercury Battery Loading



Before using your Canonet G-III 17, load the mercury battery.

To open cover of the battery compartment, insert a fingernail in the open slot, sliding the cover in the direction of the arrow. By using a slight pull outward, the cover will open.

3




Insert the battery on the tab in the compartment.

■ Be sure the mercury battery is inserted only in the correct direction.

■ A 1.35V M20 (#625) mercury battery should be used—equivalent to the Mallory PX-625, or Eveready EPX-625.

Press cover to close.



Replacing Battery


When replacing the mercury battery, open the cover of the mercury battery compartment and slowly pull out the tab being careful not to let the battery drop out.

■ When the camera will not be used for a long period, remove the battery.

Battery Checking





Press the battery check button (colored red).



If the blue lamp lights up, the battery has sufficient power. Otherwise, the battery should be replaced.

■ The battery check button will not light up at temperatures of -15°C (5°F) or under. The camera will work, however, if the battery has sufficient power.


Film Loading



Canon's Exclusive Quick-Loading (QL) mechanism in the Canonet G-III 17 accepts any standard 35mm film roll in cartridge. When loading new film, always avoid direct sunlight.


To release the latch of the back cover, raise the film rewind crank, and pull it all the way up.

Open the cover fully. When the back cover is opened, the QL cover opens simultaneously. Face the film cartridge as illustrated in the line drawing inside the back cover, and insert it into the cartridge compartment. Push the crank back to its normal position.



Lay the tip of the film leader above the "amber" film set mark.

■ The QL cover automatically opens and closes with the back cover. Do not touch the QL cover.




Bring down the QL cover to hold the film in place by closing the back cover.

Look through the sprocket window to see if the film is correctly engaged with the sprocket.


■ If the film is sagging, turn the film rewind crank clockwise.

Close the back cover completely.

Pre-Settings



Wind the film advance lever until it stops. The first frame is now automatically in position.



Checking Correct Film Loading

The film is properly loaded and advanced if the film transport indicator flickers when you wind the film advance lever.

Checking Proper Winding Film

The film is wound up if the color of the film indicator turns red. The indicator turns white when the shutter is released.



Film Speed Setting

Immediately after loading film, be sure to set the ASA film speed scale in the proper position by pressing the notched film speed setting lever with your fingernail, matching the proper film speed number with the index of the ASA film speed indicator window.

■ The higher the film speed number, the more sensitive the film; the lower it is, the

less sensitive. For example, the ASA 400 film is better for shooting at low light level than the ASA 100 film.

Automatic Electric Eye Photography



For automatic Electric Eye photography, set the aperture ring at the "A" position.

■ The EE mechanism is fully coupled to the ASA film speed, the shutter speed and the aperture.



Shutter Speed Adjustment

Turn the shutter speed ring, and match the film speed setting lever with the simple exposure symbol of either sunny ☀, cloudy ☁, or indoor 🏠. With ASA 100 film for example, the shutter speeds are set at 1/500 sec. for sunny ☀, 1/125 sec. for cloudy ☁ and 1/30 sec. for indoor 🏠.



Focusing


While looking through the viewfinder, turn the focusing lever. The subject is in focus when the double image merges into one precise image in the center of the viewfinder.



Out of focus



In focus



Checking the Exposure Indicator


Point the camera at the subject and check the position of the exposure indicator inside the viewfinder.

Press the shutter button if the indicator is inside the proper exposure range.

■ The shutter cannot be released if the exposure indicator is either over- or under-exposure warning mark.

■ If the indicator points to the under-exposure warning mark, turn the shutter speed ring clockwise until the indicator moves to the proper exposure range, or use the Canolite D or other flash units.

■ If the indicator points to the overexposure warning mark, turn the shutter speed ring counterclockwise until the indicator moves to the proper exposure range, or use an ND filter.



Compose the Picture within the Frame.
The subjects which will appear on the film can be seen within the rectangular frame.



Press the Shutter Button gently to snap a picture.

Automatic Flash Photography—Using Canolite D




The Canolite D is an optional electronic flash unit with direct contact exclusively designed for the Canonet G-III 17. There is absolutely no necessity to worry about guide numbers. Night or indoor photography is now as easy as daylight photography using the Canolite D.

By simply attaching the Canolite D, the camera, while set at "A", is switched over to the automatic flash control circuit, and the proper f/stop corresponding to the shooting distance is automatically set.




- Power Source: Two 1.5V alkaline AA batteries.
- Size: 26 x 57 x 82 mm (1" x 2-1/4" x 3-1/4")
- Weight: 115 grams (4 ozs.)



Check the Exposure Indicator in the Viewfinder.

- When it is within the proper exposure range, press the shutter release button.




- If the exposure indicator is within the red mark, the subject is too far or too close. Adjust the focusing distance until the indicator shows the proper exposure.



Press the Shutter Button gently to snap a picture.

- With the Canolite D, any shutter speed can be used.

Using Other Flash Units




The Canonet G-III 17 has both a direct contact accessory shoe and conventional flash socket. Automatic flash photography is possible with flash bulbs and electronic flash units other than the Canolite D.

Insert the flash into the accessory shoe and connect its cord if it is not a cordless unit.



Three guide numbers are engraved in blue on the aperture ring. They are for ASA 100 film and distance in meters. For conversion to ASA 25 and feet see the conversion table below. With flash bulbs, set the shutter speed to 1/30 sec. Any speed may be used with electronic flash units.

Guide No.	14	20	28	(ASA 100:m)
	23	33	46	(ASA 25:ft.)




■ Do not use flash bulb (or unit) with following types of film because it does not couple properly.

Flash bulb of guide number 14 with ASA 25 film, guide number 20 with ASA 800, and guide number 28 with ASA 400 or higher speeds.

■ In flash photography using a conventional electronic flash unit or flash bulb when the proper f/stop is set according to the guide number, there is a heavy drain on the mercury battery. Therefore, be sure to return the aperture ring to the "A" position after shooting.


■ When the subject is too far or too close, the shutter button cannot be depressed.

Manual Control of Aperture




For manual control of the aperture, release the aperture ring from the "A" position. The shutter speed and f/stop can be freely set for achieving specialized technical effects. With the Canonet G-III 17, special effects in high tone or low tone can be obtained in the same manner as with more professional cameras.

■ In manual exposure control, the position of the exposure indicator is in the upper red mark.



Using Self-timer



The Canonet G-III 17 has a built-in self-timer. To operate the self-timer, turn the self-timer lever in the direction of the arrow until it stops. The shutter will be released approximately 10 seconds after the shutter button has been pressed.



- The self-timer also operates when taking pictures with flash units.
- If the self-timer lever is set, do not return it to the normal position. It is automatically returned, after the picture is snapped.



Bulb Exposure



Bulb exposure is used when taking pictures with long time exposures. Release the aperture ring manually from "A" to the desired f/stop.



Set the shutter speed ring at the "B" position while pressing down on the bulb setting lever.




Press the shutter button gently.

The shutter will remain open as long as the shutter button is pressed and will close when the shutter button is released.


■ When an extended time exposure is being made, use the Canon Release, and tripod, to avoid blurred pictures.

Film Rewinding




When the film reaches the end and the film advance lever stops, rewind the film into the cartridge as soon as possible. Be sure not to open the back cover before rewinding; otherwise, the entire roll will be exposed and ruined since the film will be exposed within the camera.


To rewind, press in the rewind button.



Raise the film rewind crank, turning it in the direction of the arrow, until the film is completely rewound in the cartridge.



Watch the film transport indicator, and stop rewinding when red and white lines cease to flicker.



Film Removing

Open the back cover by pulling up the rewind crank fully, and remove the film cartridge.

Technical Data

Type: 35mm lens shutter type camera with Electric Eye.

Picture Size: 24mm X 36mm

Lens: Canon Lens 40mm f/1.7. 6-element 4-group construction, with four newly designed glasses. Spectra coated in amber and purple.

Viewfinder: Viewfinder combined with range-finder, bright frame with automatic parallax correction, aperture scale, exposure indicator and over/under exposure indicator and over/underexposure warning marks.

EE Mechanism: Built-in exposure meter with CdS cell for fully automatic exposure control. Shutter speed priority system. ASA 25 to 800 (DIN 15 to 30). With ASA 100 film, EV 3.5 (f/1.7 at 1/4 sec.)—EV 17 (f/16 at 1/500 sec.). Powered by one 1.35V M 20 (#625) mercury battery. Battery checker built-in.

Manual Control of Aperture: Possible at any desired f/stop by releasing EE mechanism.

Shutter: Between-the-shutter. Shutter speeds from 1/4 to 1/500 sec. and B. Automatically sets aperture, self-cocking combined film/shutter wind, self-timer, X-synchronization.

Flash Contact: Accessory shoe with direct contact exclusive for Canolite D and the flash socket for the other flash units.

Canolite D: Exclusive electronic flash unit designed for the Canonet G-III 17 with direct contact for cordless type. When performing flash photography, it is not necessary to worry about guide numbers or to calculate f/stops. Automatic setting of proper f/stop is possible as the EE circuit is coupled to the shooting distance. Canolite D is powered by two 1.5V alkaline AA batteries.

Flash-Auto Mechanism for Other Flash Units: Aperture openings coupled to shooting distance at guide numbers 14, 20, 28 (m) with ASA 100. Shutter button is locked when it is outside the coupling range.


Film Loading: Canon-developed QL (Quick Loading) mechanism. Accepts any standard 35mm film in cartridge.

Film Advance: Single-stroke 127°. Film transport indicator and film indicator are built-in.

Frame Counter: Resets automatically.
Size: 120X75X60mm (4-3/4"X3"X2-3/8")
Weight: 620 grams (1 lb. 5-7/8 ozs.).

Subject to change without notice

Accessories



- Lens Hood
- Canolite D
- Canon Release 30
- Canon Release 50

- Filter 48 mm
(Y1, Y3, O1, G1, R1, UV, ND-4, ND-8
Skylight, CCA 4, 8, 12, CCB 4, 8, 12)
- Gadget Bag 4
- Hard case for Canonet G-III 17



CANON INC. 11-28, Mita 3-chome, Minato-ku, Tokyo 108, Japan

U.S.A.	CANON U.S.A., INC. HEAD OFFICE 10 Nevada Drive, Lake Success, Long Island, N.Y. 11042, U.S.A. CANON U.S.A., INC. MANHATTAN SERVICE STATION 600 Third Avenue, New York, N.Y. 10016, U.S.A. CANON U.S.A., INC. ATLANTA OFFICE 6380 Peachtree Industrial Blvd., Norcross, Georgia 30071, U.S.A. CANON U.S.A., INC. CHICAGO OFFICE 140 Industrial Drive, Elmhurst, Illinois 60126 U.S.A. CANON U.S.A., INC. LOS ANGELES OFFICE 123 Paularino Avenue East, Costa Mesa, California 92626, U.S.A. CANON U.S.A., INC. LOS ANGELES SERVICE STATION 3407 West 6th Street, Los Angeles, California 90020, U.S.A. CANON U.S.A., INC. SAN FRANCISCO SERVICE STATION 776 Market Street, San Francisco, California 94102, U.S.A. CANON U.S.A., INC. HAWAII OFFICE Bldg. B-2, 1050 Ala Moana Blvd., Honolulu, Hawaii 96814, U.S.A.
CANADA	CANON OPTICS & BUSINESS MACHINES CANADA, LTD. HEAD OFFICE 3245 American Drive, Mississauga, Ontario L4V 1N4, Canada CANON OPTICS & BUSINESS MACHINES CANADA, LTD. MONTREAL OFFICE 3070 Brabant-Marineau Street, St. Laurent, Quebec H4C 1K7, Canada CANON OPTICS & BUSINESS MACHINES CANADA, LTD. VANCOUVER OFFICE 5900A, No. 2 Road, Richmond, B.C. V7C 4R9, Canada CANON OPTICS & BUSINESS MACHINES CANADA, LTD. EDMONTON SERVICE CENTER 5222-86 St. Edmonton, Alberta T6E 5J6, Canada
EUROPE AFRICA & MIDDLE EAST	CANON AMSTERDAM NV P.O. Box 7907, 1008 AC Amsterdam, The Netherlands CANON AMSTERDAM NV CAMERA SERVICE CENTER Gebouw 70, Schiphol Oost, The Netherlands
CENTRAL & SOUTH AMERICA	CANON LATIN AMERICA, INC. SALES DEPARTMENT P.O. Box 7022, Panama 5, Rep. of Panama CANON LATIN AMERICA, INC. REPAIR SERVICE CENTER P.O. Box 2019, Colon Free Zone, Rep. of Panama
SOUTHEAST ASIA	CANON INC. HONG KONG BRANCH 5th Floor 2-6, Fui Yiu Kok Street, Tsuen Wan, New Territories, Hong Kong
OCEANIA	CANON AUSTRALIA PTY. LTD. 22 Lambs Road, Artarmon, Sydney 2054, Australia